




**ENVIROGRAF®**




# INTUMESCENT DOWNLIGHTER COVERS


## PRODUCT 32: STEP-BY-STEP FITTING INSTRUCTIONS FOR DOWNLIGHTER COVERS IN PLASTERBOARD CEILINGS




1 Lead the cable from the transformer through the previously-cut downlighter fitting aperture




2 **SIDE CABLE ENTRY**  
Pierce the side cable entry point with a sharp object to suit the cable size and feed sufficient cable through this hole for the connection




3 Compress the cover to fit into the opening and push it into ceiling void. Maintain contact



4 Use the two supplied pins to fasten two opposite inner flanges of the cover to the plasterboard



5 **VIEW FROM ABOVE**  
Use a hammer/screwdriver handle to open out the cover material away from the light fitting




6 Insert the light fitting into the hole and allow the clips to fasten over the inner flaps of the cover. The fitting is now protected by a secure cover.

### IMPORTANT

**PLEASE ENSURE THAT ANY FITTED CEILING INSULATION MATERIAL DOES NOT COMPRESS THE LIGHTING COVER**



**PROTECTING PROPERTY  
PROTECTING LIVES**



COPYRIGHT © 2008 INTUMESCENT SYSTEMS LTD

Intumescent Systems Ltd, Envirograf House, Barfrestone, Dover, Kent, CT15 7JG, United Kingdom

Phone: +44 (0) 1 304 842 555 – Fax: +44 (0) 1 304 842 666 – Email: sales@envirograf.com – URL: www.envirograf.com